

Programming Remotes For Use with Amino

Searching for Your Code

If your device does not respond the remote after trying all codes listed for your brand television, or if your brand is not listed, try searching for your code:

1. Turn television on.
2. Press a device key once
3. Press and hold **SETUP** until red LED blinks twice, then release
4. Enter **991**, then the device group number (see table below.)
The LED blinks twice

Code	Device Group
0	Cable (Cable Converters)
1	TV(TVs)

5. Aim the remote at the device and press **Power**. The remote sends IR codes from its library to the selected device, starting with the most popular code first. If the television turns off, go to step 7.
6. If the TV does not turn off, press **CH+**. The remote will try the next code. Continue until the TV turns off.

Note: Press **CH-** to try the previous code

7. To set the code, press **SETUP** once. The LED blinks twice.
8. To search for other device codes, repeat steps 1 to 7.